



# PRO PATCH SUPREME™

## 2. MANUFACTURER

### PROMA ADHESIVES Inc.

9801, Parkway, Anjou, Quebec Canada H1J 1P3

Tel.: 514.852.8585

Fax: 514.852.8225

Toll-free: 1 866.51.PROMA (77662)

Email: info@proma.ca

Web: www.proma.ca

## 3. PRODUCT DESCRIPTION

PRO PATCH SUPREME™ is a universal, superior-performance, fast-setting, fast-curing, polymer-modified calcium aluminate cement-based patching compound that, when mixed with water, is designed to fill cracks, depressions, voids and holes in a substrate up to 12 mm (1/2") deep. PRO PATCH SUPREME™ can also be used, without the addition of a latex additive, as an embossing leveler over conventional and non-conventional substrates prior to the installation of a floor covering (see PROMA's Surface Preparation Guidelines for details).

### Features

- ◆ Patch from featheredge up to 12 mm (1/2") in a single application
- ◆ FAST-SETTING: install flooring after only 60 – 90 minutes
- ◆ Mix only with water
- ◆ For interior institutional, commercial and residential applications
- ◆ Compatible with all adhesives and floor coverings including wood parquet and rubber
- ◆ Use as an embossing leveler
- ◆ Blocks pH when installed greater than 5 mm (3/16") thick
- ◆ Will not promote mold, mildew or bacteria growth
- ◆ No VOC
- ◆ Product characteristics improves indoor air quality compared to Portland cement-based products
- ◆ Eco friendly for users of the material
- ◆ Contributes to LEED® objectives and requirements

### Packaging

10 kg (22 lb) bag



### Suitable Substrates

- ◆ Dry, completely cured concrete (at least 28 days old)
- ◆ Concrete and masonry blocks
- ◆ Cement backer units (CBU)
- ◆ Gypsum and light-weight concrete surfaces†
- ◆ Gypsum wallboard (INTERIOR dry areas only)
- ◆ Existing ceramic and quarry tiles, porcelain, granite and marble\*
- ◆ Epoxy Terrazzo floors†
- ◆ Cementitious Terrazzo floors\*
- ◆ Exterior Grade Douglas Fir Plywood, certified CANPLY (SELECT) or (SEL-TF) CSA 121, for INTERIOR Residential Light-Duty Floors in dry areas only
- ◆ Metal such as steel, copper, stainless steel, aluminum or lead†
- ◆ Old cut-back adhesive **residue** and water-soluble adhesive **residues**\*
- ◆ Existing VCT tiles and non-cushioned vinyl sheet goods\*
- ◆ Cementitious screeds, rendering, leveling coats and mortar beds
- ◆ Homogeneous PVC flooring†
- ◆ Resin-based floor coverings (epoxy, urethane or polyurethane)†

† When primed with PRO SUPERPRIME™ (see respective data sheet for details)

\* With adequate prior preparation as indicated in PROMA's "Surface Preparation Guidelines" or respective data sheet



Concrete

Exterior-Grade Plywood

Cutback Adhesive Residue

Existing VCT and Non-Cushioned Vinyl Sheet Goods

Existing Tile



## Limitations

- ♦ For INTERIOR installations only.
- ♦ Do not use at temperatures below 10°C (50°F) or above 35°C (95°F).
- ♦ Do not use for applications exceeding 12 mm (1/2") in thickness. For installations exceeding 12 mm (1/2"), use PRO PLAN™, PRO BETOPLAN™, PRO FLOWLEVEL 40™ or PRO CEMIX™ (see respective technical data sheets for details).
- ♦ Do not apply directly over particleboard, chipboard, presswood, Lauan, masonite, OSB and other dimensionally unstable materials.
- ♦ Do not use over any type of cushioned flooring surface.
- ♦ Allow the patching product to dry properly prior to installing the floor covering.
- ♦ Do not leave without floor covering or exposed as a resurfacing material.
- ♦ Existing epoxy terrazzo floors, metal, epoxy-resin floors and Homogeneous PVC flooring must be well prepared and primed with PRO SUPERPRIME™ prior to installing the patching product (see respective technical data sheet).
- ♦ Existing Gypsum and light-weight concrete surfaces must be properly primed with PRO SUPERPRIME™ (see respective technical data sheet for details).
- ♦ Do not use where high moisture and hydrostatic conditions and/or recurring moisture problems exist.
- ♦ Do not use in places subject to immersion, to standing water or permanent humidity.
- ♦ Do not add water to the mix once it begins to thicken.
- ♦ Do not add sand, aggregate or a latex additive to the mix.
- ♦ Protect from any direct air ventilation or heat radiation source, such as direct sunlight, during and after the installation, for a minimum of 24 hours. These conditions could cause the patching product to cure too rapidly, resulting in micro-cracking.
- ♦ **Do not accelerate curing time by using ventilators or heating appliances.**

## 4. TECHNICAL DATA

### Applicable Standards

For Additional Information, please refer to the most recent TCNA handbook for ceramic tile installation or the TTMAC Specification Guide 09 30 00 Tile Installation Manual, or visit our website at [www.proma.ca](http://www.proma.ca).

| WORKING PROPERTIES (@23° C [73° F] and 50% RH) |               |
|--|---------------|
| Working time                                   | 10-15 minutes |
| Final set                                      | 45 minutes    |
| Time before installing floor covering          | 60-90 minutes |

| PHYSICAL PROPERTIES (@23° C [73° F] and 50% RH)                                   |  |
|---|--|
| VOC content   | 0 g/L                                    |
| Compressive strength (ASTM C-109) @ 28 days                                       | > 37.2 MPa (5,400 psi)                   |
| Density   | 1.7 g/mL                                 |
| Approximate coverage per 10 kg (22 lb) bag  |  |
| Thickness   | Coverage                                 |
| 1.5 mm (1/16")  | 5.6 m <sup>2</sup> (60 ft <sup>2</sup> ) |
| 3 mm (1/8")   | 2.8 m <sup>2</sup> (30 ft <sup>2</sup> ) |
| 6 mm (1/4")   | 1.4 m <sup>2</sup> (15 ft <sup>2</sup> ) |
| Shelf life  |  |
| 6 months if kept in its original unopened packaging and stored in a dry location. |  |

## 5. INSTALLATION

### Surface Preparation

(Refer to PROMA Surface Preparation Guidelines for complete details)

**Note: PRO SUPERPRIME™ can be used to ready nearly any surface for PROMA patching compounds without the need for scarifying or shotblasting, saving valuable time and money (see respective technical data sheet for details).**

- ♦ All supporting surfaces must be structurally sound, solid and stable.
- ♦ Surfaces must be clean and free of dust, oil, grease, paint, tar, wax, curing agent, primer, sealer, form release agent or any deleterious substance and debris which may prevent or reduce adhesion.
- ♦ Acids, concentrated alkaline conditions and cleaning chemical residues must be neutralized or removed.
- ♦ All concrete substrates must be completely cured (at least 28 days old), solid, sound, slightly textured and have a direct tensile cohesive strength greater than 1.2 MPa (175 psi) when tested in accordance with ACI 503 R – (Appendix A) procedure.
- ♦ On grade or below grade concrete slabs must be installed over an effective vapor barrier.
- ♦ All concrete substrates must be dry and free of hydrostatic conditions and/or extreme moisture problems. Perform a calcium chloride moisture emission test (ASTM F-1869) on the concrete substrate before proceeding with the installation of the floor. For wood flooring and resilient floor covering installations, the moisture vapor emission of the concrete must not exceed 1.36 kg per 93 m<sup>2</sup> (3 lb per 1,000 sq. ft.) per 24 hours. Do not prime, repair, level or patch the substrate, or install any floor covering materials until moisture problems and conditions have been addressed to meet these requirements. **Please contact our Technical Service Department for appropriate recommendations.**
- ♦ Existing Gypsum and light-weight concrete surfaces must be properly primed with PRO SUPERPRIME™ (see respective technical data sheet for details).
- ♦ Smooth concrete substrate surfaces must be either PRIMED with PRO SUPERPRIME™ primer **OR** mechanically roughened in accordance with an engineer-approved procedure (shot-blasting, scarification, grinding, sand or water-blasting, etc) to provide sufficient surface texture and profile for the adequate bonding of the subsequent patching compound (please refer to the PRO SUPERPRIME™ data sheet for full details).
- ♦ Existing concrete slabs with old cutback adhesive or carpet adhesive residues must be properly scraped, roughened and cleaned prior to the application of the patching product (please refer to the Surface Preparation Guidelines for full details or contact our Technical Service Department for appropriate recommendations).
- ♦ Existing ceramic tile, VCT and non-cushioned vinyl sheet goods should be properly prepared and cleaned prior to the application of the patching product (please refer to the Surface Preparation Guidelines for full details or contact our Technical Service Department for appropriate recommendations).

**Note:** Scrape off as much as possible of the old cut-back adhesive.

Do not use sweeping compounds. This could leave an oily film on the concrete surface that will prevent a proper bond.

### Mixing

**Mixing ratio: 2 3/4 parts powder to 1 part water (by volume)**

1. Use clean mixing-tools and containers.
2. In a clean mixing container, measure and pour **3.2 L (3.4 quarts / 0.85 US gal)** of cool clean water and gradually add 10 kg (22 lb) of PRO PATCH SUPREME™ powder mix, while mixing slowly.
3. Using a low-speed mechanical mixer (150 - 300 rpm), mix until a homogeneous, smooth, lump-free, consistency is achieved.
4. The product is now ready for use.
5. Use the product within the shortest possible delay (within a few minutes).



**PRO PATCH SUPREME™**  
used as an embossing  
leveler over existing  
ceramic tile

### Application

**Note: Protect from any direct air ventilation or heat radiation source, such as direct sunlight, during and after the installation.**

1. Spread PRO PATCH SUPREME™ immediately after mixing with the flat side of a trowel to the desired texture and finish.
2. Do not mix more material than can be used in a 10-15 minute period.
3. Do not add any water once the mixture has hardened.

**For more detailed information on ways to apply this product, please contact our technical department for proper recommendations and job field assistance.**

### Expansion and Control Joints

- ♦ Install control joints where tiles abut restraining surfaces, around the perimeter of the work and at the base of columns and curbs.
- ♦ Install and space expansion and control joints in all directions in accordance with TCNA HANDBOOK FOR CERAMIC TILE INSTALLATION Detail #EJ-171 recommendations, or TTMAC Specification Guide 09 30 00 Detail #301-MJ recommendations. CAUTION: DO NOT cut EXPANSION JOINTS in after the tiles have been installed. Install tiles normally and stop when the control joint location is reached. Cut the tile if required and resume setting from the opposite side of the joint. Before proceeding further, rake the joint and leave the tile and joint space clean.
- ♦ DO NOT FILL EXPANSION JOINT SPACE UNTIL GROUTING IS COMPLETED on the remainder of the job.
- ♦ Install a suitable industry-approved compressible bead and flexible sealant to caulk expansion and control joints. Follow the sealant manufacturer's installation instructions.

### Curing and Protection

- ♦ 60-90 minutes at room temperature (foot traffic).
- ♦ Install resilient floor covering, carpet, engineered wood and wood parquet after 60-90 minutes.
- ♦ Material should be completely dry prior to applying the floor covering adhesive.

**Note:** Drying time may vary depending on the temperature and humidity level. **Do not attempt to accelerate drying and curing through forced ventilation, fans or heat-blowers.**

- ♦ Ensure that the moisture vapor emission of the concrete does not exceed 1.36 kg per 93 m<sup>2</sup> (3 lb per 1 000 sq. ft.) per 24 hours when tested in accordance with the calcium chloride moisture emission test (ASTM F-1869) prior to the installation of a resilient floor covering or other material sensitive to water.
- ♦ Protect from traffic and dust until floor covering is completely installed.

### Cleaning

Clean tools and hands with water while the product is still fresh.

### Health and Safety

Refer to the Material Safety Data Sheet (MSDS) for complete details.

## PRO SUPERPRIME™

PROMA has engineered a revolutionary primer that can ready nearly any surface for patching compounds without the need for scarifying or shotblasting. Use PRO SUPERPRIME™ with PRO PATCH SUPREME™ as an unbeatable system for preparing a substrate for flooring installation. Surface must meet a minimum of 0.5 MPa (72 psi) tensile bond strength. In areas subject to heavy traffic, a minimum of 1.2 MPa (175 psi) tensile bond strength is required (see respective technical data sheet for details).



|                          |  |                        |  |  |                  |                    |
|--------------------------|--|------------------------|--|--|------------------|--------------------|
| Cured concrete (28 days) | Metal such as steel, copper, stainless steel, aluminum or lead | Exterior-grade plywood | Existing ceramic and quarry tiles, porcelain, granite and marble | Existing VAT, VCT, non-cushioned vinyl sheet goods, homogeneous PVC flooring | Adhesive residue | Painted substrates |
|                          |  |                        |  |  |                  |                    |



## 6. AVAILABILITY AND COST

PROMA products are widely available in Canada and the Northeast United States. To find a distributor of PROMA products, call **toll-free: 1.866.51.PROMA (77662)**.

## 7. WARRANTY

PROMA warrants that this product is manufactured using quality raw materials and is of merchantable quality and suitable for the purpose for which it was intended. PROMA's liability under this warranty shall be limited to the replacement of its product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising from the use of/or the inability to use this product.

## 8. MAINTENANCE

Product requires no special maintenance. Do not leave without floor covering or exposed as a resurfacing material.

## 9. TECHNICAL SERVICE

For more detailed information on this product, please contact our technical department for proper recommendations and job field assistance. **Toll-free: 1.866.51.PROMA (77662)**.

## 10. FILING SYSTEM

Additional information is available upon request, or by visiting [www.proma.ca](http://www.proma.ca).

---

### **PROMA Adhesives Inc.**

9801, Parkway, Anjou, Quebec Canada H1J 1P3

Tel.: 514.852.8585

Fax: 514.852.8225

Toll-free: 1 866.51.PROMA (77662)

Email: [info@proma.ca](mailto:info@proma.ca)

© 2013 PROMA Adhesives, Inc.